

## Internal Wrench

- Holds closet spuds and bath, basin and sink strainers through 2". Use to install or extract 1" through 2" nipples.
- Jaws expand by eccentric action and are reversible for various sizes.



Catalog No.	Model No.	Description	Nom. Size <sup>(1)</sup>		Pipe Capacity <sup>(2)</sup>		Weight		Std. Pack
			in.	mm	in.	mm	lb.	kg	
31405	342	Internal	4½	113	1 - 2	25 - 50	1½	0,7	1