### **WRENCHES**

# **Heavy-Duty Pipe Wrenches**

#### Straight Pipe Wrench

• Sturdy, cast-iron housing and I-beam handle with full floating forged hook jaw, featuring selfcleaning threads with replaceable hook and heel jaws.



Catalog No.	Model	Nom. Size <sup>(1)</sup>			ipe acity <sup>(2)</sup>	We	Std. Pack	
NO.	No.	in.	mm	in.	mm	lb.	kg	Pack
31000	6	6	150	3,4	20	1/2	0,2	6
31005	8	8	200	1	25	3,4	0,3	6
31010	10	10	250	11/2	40	13⁄4	0,8	6
31015	12	12	300	2	50	23/4	1,2	6
31020	14	14	350	2	50	31⁄2	1,6	6
31025	18	18	450	<b>2</b> <sup>1</sup> ⁄ <sub>2</sub>	65	53/4	2,6	6
31030	24	24	600	3	80	93/4	4,4	3
31035	36	36	900	5	125	19	8,7	1
31040	48	48	1200	6	150	34¹⁄4	15,6	1
31045	60	60	1500	8	200	51 <sup>1</sup> /4	23,3	1

#### RapidGrip®

- · Quick one-handed operation makes your jobs mov
- The spring-loaded jaw design provides rapid action.
- Unique combination heel/hook jaw design aggressively bites the work piece and ensures secure grip.



9	Catalog		Nom. Size <sup>(1)</sup>		Pipe Capacity <sup>(2)</sup>		Fittings Capacity <sup>(3)</sup>		Weight		Std.
	No. No.	in.	mm	in.	mm	in.	mm	lb.	kg	Pack	
Ì	10348	10	10	250	1 <sup>1</sup> /2	40	1	25	1.6	0,7	1
	10358	14	14	350	2	50	11/2	40	3.1	1,4	1

#### **End Pipe Wrench**

- Assures a fast and easy grip for pipe working in restricted spaces or close to a wall.
- Provides a faster, easier way to get a grip and long handle swing.
- Ideal for pipe work close to a wall, in tight quarters or in closely-spaced parallel lines.



Catalog Model No. No.		Nom. Size <sup>(1)</sup>			pe city <sup>(2)</sup>	We	ight	Std. Pack	
NO.	INO.	in.	mm	in.	mm	lb.	kg	Pack	
31050	E-6	6	150	3,4	20	1/2	0,2	6	
31055	E-8	8	200	1	25	3,4	0,3	6	
31060	E-10	10	250	11½	40	13⁄4	0,8	6	
31065	E-12	12	300	2	50	23/4	1,2	6	
31070	E-14	14	350	2	50	31/2	1,6	6	
31075	E-18	18	450	2 <sup>1</sup> /2	65	5 <sup>3</sup> ⁄4	2,6	6	
31080	E-24	24	600	3	80	9 <sup>3</sup> ⁄4	4,4	6	
31085	E-36	36	900	5	125	19	8,7	1	

- (1) Nominal size = length of handle.
  (2) Pipe capacity = maximum nominal diameter of steel pipe.
  (3) Fittings capacity = maximum nominal diameter of fitting.

When using a pipe wrench, a gap must be maintained between the shank of the hook jaw and the pipe or fitting. This permits the two gripping points (the heel and the teeth of the hook jaw) to produce the gripping action of the wrench.

# **WRENCHES**

#### Raprench® Wrench

- A deeper and broader hook jaw housing provides a smooth, flat surface that is ideal for occasional use as a hammer.
- Offers all of the same outstanding qualities found in all RIDGID® heavy-duty wrenches.



Catalog No.	Model Nom. Size(1)		Size <sup>(1)</sup>	Pi Capa		We	ight	Std.
NO.	No.	in.	mm	in.	mm	lb.	kg	Pack
31395	10	10	250	11/2	40	2	0,9	6

#### **Heavy-Duty Offset Pipe Wrench**

- Features a jaw opening parallel to the handle and a narrower hook jaw head.
- Provides easy entry into tight spots.



Catalog	Catalog Model No. No.		Nom. Size(1)		Pipe Capacity <sup>(2)</sup>		ight	Std. Pack
NO.	NO.	in.	mm	in.	mm	lb.	kg	rack
89435	14	14	350	2	50	21/4	1,0	6
89440	18	18	450	21/2	65	53/4	2,6	6
89445	24	24	600	3	80	93/4	4,4	6

## **Compound Leverage Wrench**

- A unique design multiplies the turning force applied to a pipe.
- Ideal for freeing locked couplings and joints frozen by age or damage.
- Replaceable jaws are hardened alloy steel.



Catalog No.	Model No.	Nom.	Size <sup>(1)</sup>	Pi Capa		We	ight	Std. Pack
NO.	NU.	in.	mm	in.	mm	lb.	kg	Fack
31375	S-2	-	-	2	50	71/4	3,3	1
31380	S-4A	_	_	5	125	331/2	15,2	1
31385	S-6A	_	_	6	150	451/2	20,6	1
31390	S-8A	-	_	8	200	681/2	31,1	1



For wrench replacement parts, see page 1.9.



<sup>(1)</sup> Nominal size = length of handle. (2) Pipe capacity = maximum nominal diameter of steel pipe.